

Book order No.	Description	Alstom Part Number
103	Cap Screw	NP-151108050
110	Set Screw	NP-117310030
111	Set Screw	NP-117308025
112	Set Screw	NP-117306016
114	Set Screw	NP-117712030
130	Tab Washer	NP-024802
131	Tab Washer	NP-BSSP42/N
132	Tab washer	NP-028804
133	Tab Washer	NP-SL683/027
135	Tab washer	NP-024803
147	Bolt	NP-111710045
160	Nut	NP-211114010
163	Nut	NP-2111144010
177	Stud	NP-193310045
185	Tab washer	NP-SL617/006
187	Washer Plain	NP-231111006
195	O-Ring seal	NP-351160271
202	Heat Shield Assy.	NP-BF1205
208	Seal Plate	NP-BF2605
210	Adj Shim Solid	NP-BF2602
211	Adj. Shim Peelable	NP-BF2608
229	Shroud Ring H	NP-ND41143
300	Rotor Assy	NP-BF4008/23
301	Impeller 4 H	NP-BF4649/04
303	Lock Nut	NP-BF4872
304	Locking washer	NP-BF4873
305	Shaft Nut	NP-BF4875
401	Insert Cap	NP-BF3813/04
403	Diffuser 4F157	NP-BF3708/33

Book order No.	Description	Alstom Part Number
405	C/O CSG (Sump Half)	NP-BF3303
406	Set Screw	NP-8H3916
407	Oil Seal Bush	NP-BF3915
413	O-Ring	NP-BF3917
416	Long Lok Screw	NP-BF1041
509	Air Oil Seal Bush	NP-ND41069
517	O-Ring	NP-BF0915
518	Nozzle Assy H243	NP-BF0750H/03
800	Bearing HSG Assy	NP-BF3520
801	Bearing Bush	NP-BF2512
802	Thrust Plate Major	NP-BF3550
803	Thrust Plate Minor	NP-BF3503
806	Impeller Adj. Shim	NP-BF3575
808	Speed Meas. Head	NP-BS06J151/2
820	Joint	NP-BF3653
900	Bearing Assy T/E	NP-BF0520
901	Bearing Bush	NP-BF2512
911	Joint TC	NP-BF0664
300-A	Rotor Blade H IVY 61in set	NP-BF4232/02
300-B	Lacing Wire 1	NP-BF4851/01
300-C	Lacing Wire 2	NP-BF4851/02
300-D	Blade Locking Tab 61in set	NP-BF4842
XXX1	Loctite RTV2	NP-TMSC130/92
XXX2	Spare Set NA450/455/457	NP-TMSC130/346